

Brookstone®

WeatherCast

wireless 5-day forecaster



BB
BB

WeatherCast

wireless 5-day forecaster

BETTER BY BROOKSTONE®

We believe that exacting standards are the core of our success. This product has been thoroughly tested to be certain it meets our rigorous quality control criteria.

With WeatherCast, real-time weather information is received wirelessly from AccuWeather.com®—no wires, PC or subscription needed. Simply enjoy weather forecasts for up to 150 cities. Includes “Feels Like” which accounts for wind chill and heat index information.

WARNING

1. Use indoors only.
2. Close attention is necessary when this unit is operated near children. Do not allow children to play with this unit. It is not a toy.
3. Do not allow children to play with any plastic bags that accompany this unit. Plastic bags may present a hazard to young children.
4. Do not use attachments not recommended by manufacturer.
5. Never operate this unit if it is not working properly, if it has been dropped, damaged or dropped into water.
6. The unit should be situated away from heat sources such as direct sunlight, radiators, heat registers, stoves or other heat-producing appliances.
7. Never drop or insert objects into any openings.
8. Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury.
9. Do not perform any servicing on the unit.
10. Do not try to disassemble unit. High voltage inside.

BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

FCC COMPLIANCE INFORMATION


This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protections against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with these instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Note: If harmful interference to radio or television reception should occur, determined by turning the product off and on, the user is encouraged to correct interference by trying one or more of the following measures:


- Relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect product to an outlet on a circuit different from receiver.
- Consult an experienced radio/TV technician for help.

LOCATION OF CONTROLS

1. HANGING HOLE
2. CITY SELECTOR
3. CELSIUS/FAHRENHEIT SELECTOR
4. BATTERY COMPARTMENT COVER
5. FAVORITES SELECTOR
6. TIMEZONE SELECTOR
7. STAND (2 VIEWS)



DISPLAY ICONS



WEATHER ICONS

Sun



Partly Cloudy



Cloudy



Blustery



Wind and Rain



Snow



Drizzle



Wintry Mix



Cloudy and Windy



Thunderstorms



Sun and Wind




Flurries



WEATHERCAST OPERATION

INSTALLING THE BATTERIES

1. Open the BATTERY COMPARTMENT COVER.
2. Insert three AA batteries (not included) according to battery indicators inside the compartment.
3. Close the BATTERY COMPARTMENT COVER.
2. Once the batteries are inserted, the WeatherCast will give you a brief introduction to the different symbols used on the screen. Following the instructional demonstration, the temperatures will be replaced with dashes until the first update is received.
4. Place your WeatherCast in an area where it receives good signal.
5. Check the signal strength indicator **ambient** on the front of the device. If you are only getting one bar, try moving unit towards a window, or going upstairs—two or three bars of signal strength are ideal.

Note: The unit automatically receives weather forecast from one to four hours of installing the batteries and updates continuously as the forecast changes.

ADJUSTING THE TIME ZONE

Press the TIMEZONE button, located on the rear of the unit, to select your timezone. The available time zones are:

ATLANTC TZAtlantic Standard Time

EASTERN TZEastern Standard Time

CENTRAL TZCentral Standard Time

MTN TZMountain Standard Time

ARIZONA TZMountain Standard Time

PACIFIC TZPacific Standard Time

ALASKA TZAlaska Standard Time

HAWAII TZHawaii Standard Time

All time zones except ARIZONA TZ will automatically adjust for daylight savings time.

Once you see the time zone you want, wait about 7 seconds and the text TZ SET will appear to indicate the time zone setting has been saved.

SELECTING LOCATIONS



The unit provides the forecast for 152 locations in the United States.

Press the CITY buttons on the rear of the unit repeatedly until your desired location appears on the display. The locations are organized alphabetically by state, and you can move through the list by pressing the CITY UP and CITY DOWN buttons as needed.

Note: Press and hold CITY buttons to scroll through the list faster.

“FAVORITES” PRESET BUTTON

You can store up to five locations from the list of 152 cities as favorites.

1. To save a favorite, simply press and hold the FAVORITES button when the desired location appears on the screen. The  icon will illuminate for 5 seconds.
2. To remove a favorite, press and hold the FAVORITES button while on the selection you wish to remove, and the  icon will disappear.
3. A short press of the FAVORITES button will allow you to scroll through favorite locations.

Note: If you try to add a Favorite when you have already assigned five Favorites, you will see the message “FAVORIT FULL” flash on the screen. You will need to delete an existing Favorite before you can add another. Favorites settings will be preserved when batteries are removed.

VIEWING TEMPERATURE IN CELSIUS

The unit automatically displays the temperature in Fahrenheit.

To view the temperature in Celsius, use a small pointed object to press and hold the F/C button located inside the battery compartment. Screen will show CELSIUS for 5 seconds. Repeat this process to change back to Fahrenheit and the screen will show FAHRHT for 5 seconds.

“FEELS LIKE” TEMPERATURE

Your WeatherCast shows the current “feels-like” temperature. This is a combination of wind-chill in the winter and heat-index in the summer.

Note: When you first power-up your device, the “feels-like” temperature may not appear at the same time as the regular temperature.


USING THE STAND

Flip out the clear LEG STAND on the back of the housing of the unit to make it free-standing.

HANGING THE UNIT

Insert a nail or screw into your desired spot on the wall and place the HANGING HOLE over it. Or, use the built-in magnet by placing the unit against a metal surface.

“NO COVERAGE” MESSAGE

 will appear when your device has been unable to receive signal for an extended period. Check our map at <http://map.myambient.com> to ensure that your location receives coverage from our network.

BATTERY LOW INDICATOR

 flashes when the device's batteries are low and need to be replaced.

TROUBLESHOOTING GUIDE

ISSUE

RESOLUTION

Display shows no information.

Ensure batteries are fresh and installed correctly.

No network signal.

Go to <http://map.myambient.com> and enter your zip code. If you are in an area without a lot of coverage, move the device to another location in your home or office for better reception.

Time is not correct.

Press the TIMEZONES button until the correct area is displayed.

TROUBLESHOOTING GUIDE

ISSUE

Only part of the screen is showing any data.

RESOLUTION

We send data to your WeatherCast in discrete parts, so if your unit is only showing data on one part of the screen, or only some of the 150 cities, it's likely that the next update your unit receives will remedy this situation. If you've waited four hours or more without seeing the rest of the screen display data, there may be a problem with your device.

I don't see any bars next to the signal strength indicator.

This means that you're in an area that has poor reception. Try moving the unit closer to a window or upstairs. If you've moved it all over and still don't get any bars of signal, go to <http://map.myambient.com> to check your area for signal coverage.

TROUBLESHOOTING GUIDE

ISSUE

The time on my clock is off by a number of hours.

RESOLUTION

Press the TIMEZONE button on the back of the device until the proper time appears.

My clock's time is correct, but it still shows an incorrect or outdated forecast.

This is almost always the result of “lagging,” a condition that occurs when your device is not receiving a consistently strong signal. Try changing the location where you keep the WeatherCast. We recommend that you keep it somewhere where it shows at least two bars of signal strength.

TROUBLESHOOTING GUIDE

ISSUE

The temperature outside is different from what the device is saying.

RESOLUTION

The temperature readings and forecasts on your WeatherCast aren't received from a local sensor—the information comes from wireless updates from Accuweather.com®. Also, the current outside temperature may vary from the meteorological information we receive for your location.

Will this device work outside of the United States?

Sorry, at present we only send data to Ambient Devices within the United States.

TROUBLESHOOTING GUIDE

ISSUE

RESOLUTION

What can I do to improve battery life?

Your WeatherCast is designed to use very little battery power when it receives a strong signal. If it's in an area with inconsistent or weak signal, it will work harder to make sure it updates properly. The best thing you can do is ensure it's in an area where it receives three bars of signal strength.

I have a question that's not answered here.

Please visit our support site:
www.myambient.com/support
Call: 1-866-311-1999; 9AM to 5PM, EST
Or contact us anytime:
support@ambientdevices.com

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser (“Warranty Period”). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone’s property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone’s property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at **1-800-292-9819**. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the “Brookstone” trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may



provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products “as is.” This warranty does not apply to: a) damage caused by failure to follow instructions relating to product’s use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold “as is” including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.



BETTER BY BROOKSTONE® WE CREATE PRODUCTS TO MAKE LIFE BETTER. THROUGH INNOVATIVE DESIGN, BEST-IN-CLASS PRODUCT SELECTION AND AN UNYIELDING COMMITMENT TO EXCELLENCE, WE MAXIMIZE THE QUALITY OF OUR PRODUCTS—AND HELP YOU ENHANCE THE QUALITY OF YOUR LIFE.

Merrimack, New Hampshire 03054 • Customer Service 800-846-3000 • www.Brookstone.com